

#### **MEASUREMENT GUIDE**

- Important Notes Before Start:
- 1. "Measure over your usual Skydiving clothing. This means if you jump in cold weather, wear all the layers that you normally wear. Make sure you take everything out of your pockets! Also waer usual footwear that you wear for Skydiving".
- 2. "Have someone else take your Measurements".
- 3. "Be sure to use a dressmaker's tape. Ensure that the tape is flat & that you have not added any twists in the tape.
- 4. "The tape should not be too tight or too loose when measuring. Also do not add or subtract to the measurements to get a different fit. Please tell us but fit you would like, tight, regular or loose.
- **5.** "Measure 3 times to be sure if you are between a measurement, round up to the higher measurement.
- 6. "If you are unsure of any Point of Measurement still, So please ask us!


info@skypirats.com


7. Getting the correct measurements is vital your suit fitting properly!!

Happy Measuring!!!



Please take measurements according to following Diagrams the numbers of the photos match those of the form, make sure you put them in the correct place and do not leave any to fill in







### 3: Chest

P Around the Fullest part of your chest with your Arms down at your Sides.

Be sure the Tape is Level & do not over inflate your Chest.....



### 4 : Waist

Around your Waist, Level with your Bellybutton.....



## 5 : Hips/Butt

With your Feet together, Measure around the Widest Part of your Hips. Be sure that the Tape Measure is Level all the way around.......



### 6: Thigh



Around the Largest Part of your Upper Thigh......



#### 7: Calf



Around the Largest Part of your Calf......



#### 8--(a): Inseam

From Crotch to Ankle: Position the tape at the highest point on the leg at the Groin. For Guys, This is just behind your man Bits. Tape should be close along the Leg to the Ankle Bone......



### 8<sub>--(b)</sub>: Inseam

From Crotch to Floor :Position the tape at the highest point on the leg at the Groin. For Guys, This is just behind your man Bits. Tape should be close along the Leg to Floor with your Shoes On......



## 9 : Bicep


Take Measurement on Predominat Hand, with Bicep Flexed. Measure the Widest Part...





#### 11: Arm Length

Please Measure from the Ending Point of your Shoulder Bone to your Wrist.. (According to the Red Marks)......



#### 12 : Shoulder



Measure form Shoulder Point to Shoulder Point...



### 13: Torso

Total Torso: (13-1)
From the Hole of your
Throat, Measure along
the Front of the Body
through the Legs,
(13-2) Along the Back to
the Bone at the Base of
the Neck.

Be sure the Tape is not Too Tight & not Too Loose....

It should Fit Comfortable at the Crotch.....





(14-1) Place the start of the Tape measure at the top of the front of your Pant Waistband, (14-2)While holding the Tape at the front, pull the Tape through your legs to

14: Waist to Waist/Crotch

the top fo the Back of your WaistBand.

Note: Do not Wear Loose or Baggy Pants

while taking this Measurement. Also Be sure the Tape is not too Tight & not too Loose......



### 15 : Weight

F


Please take your Total Body Weight.....



### 16: Wrist

F

Around the Wrist at the Bone.....



# 17 : Total Body Height



Please Stand Straight & Take Measurement from upper Head to Floor without Shoes. Be Sure that Tape is Straight between Head & Floor......



